Plastisol screen printing in Los Angeles: what the process involves

What plastisol screen printing means

Plastisol screen printing is a way of placing ink onto fabric one layer at a time. The ink sits on top of the material rather than soaking into the fibres. Once it is heated to the right curing temperature, it forms a flexible film that becomes part of the print. That is why this method is common for shirts, hoodies, tote bags and other textile work where bold colour matters.

The basic idea is simple. A mesh screen acts as a stencil. Ink is pushed across the screen with a squeegee, and it passes through the open parts of the mesh onto the garment below. Areas blocked by stencil material stay clean. Each colour usually needs its own screen and its own pass through the press. After printing, the garment is heated so the ink sets properly.

For someone looking at plastisol screen printing Los Angeles options, the value is in knowing what happens behind the finished print. The process is not just pressing ink onto cotton. It involves artwork preparation, screen setup, alignment, printing and heat curing. Small choices at each stage affect sharpness, colour strength, feel and durability.

Preparing the artwork

Everything starts with the artwork. A design that looks fine on a screen can still print poorly if it has thin lines, tiny text or colours that blend into each other. Screen printing works best when shapes are clear and edges are deliberate. Fine detail can print, but it needs the right mesh, good stencil quality and careful handling.

View the location on Google Maps

Colour separation is the first major decision. A one-color printing job uses a single screen and one ink layer. A design with several colours needs separations, which are separate stencil layers for each ink. Designers often look for ways to reduce the number of colours without losing the look of the artwork. Fewer colours usually mean less setup and less chance of misalignment.

The fabric colour also matters. Plastisol ink is opaque enough to cover many garments, but dark fabric can still change how colours appear. A bright red on a black shirt may look different from the same red on white cotton. Some jobs need an underbase, which is a printed layer that helps top colours stay bright on dark material.

Building the screen stencil

A screen is a frame with a fine mesh stretched across it. The mesh holds the stencil and controls how much ink passes through. Lower mesh counts allow more ink to move, which suits bold areas and opaque prints. Higher mesh counts release less ink and can hold finer detail. The right choice depends on the design, the fabric and the effect wanted.

The screen is coated with emulsion coating, a light-sensitive layer spread over the mesh. Once dry, the screen is exposed to light through a film or positive of the artwork. Light hardens the parts of the emulsion that should stay closed. The areas protected from light remain soft and are washed out, leaving openings in the mesh where ink can pass.

Good screen exposure is important. Too little light can leave a weak stencil that breaks during the print run. Too much light can make the stencil hard to wash out and may leave haze in the open areas. The result is seen later as blurred edges, blocked detail or ink that refuses to release cleanly.

Screen preparation also includes checking tension and cleanliness. A loose mesh can distort the stencil. Dust, dried ink or grease can create pinholes. These problems may look small before printing, then show up across an entire batch.

Setting up the press

Once screens are ready, they are mounted on a press. Each garment is placed on a platen, the flat surface that supports the fabric during printing. The screen is lowered close to the garment, and ink is placed across the top of the mesh. A squeegee pulls the ink forward, forcing it through the open stencil areas.

Registration is the process of lining up each colour so it lands exactly where it should. In multi-colour work, even a slight shift can be visible. Color registration becomes more demanding when a design has fine outlines, small text or shapes that sit close together. Press operators check alignment, adjust micro-registration and make test prints before the full batch begins.

Off-contact is another detail that affects print quality. This is the small gap between the screen and the garment. The mesh should touch the fabric only where the squeegee pushes it. Proper off-contact helps the screen snap back cleanly, reducing smears and sticking. Too little gap can cause the stencil to drag. Too much can distort the printed shape.

Plastisol ink behaves differently from water-based ink. It does not dry in the screen in the same way, which gives printers more working time during a run. It still needs careful handling. Ink that is too thick may print heavily and feel stiff. Ink that is too loose may spread under the stencil edges. The squeegee angle, pressure and speed all change how much ink is laid down.

Printing the design

During the print run, each garment is placed in the same position on the platen. Consistency matters as much as press setup. If one shirt is shifted slightly, the print may sit lower, tilt or miss the intended area. Collars, seams and folds can all affect placement, especially on garments with uneven surfaces.

Printers usually make a few test prints before committing to the whole batch. These early prints reveal problems such as missing detail, rough edges, poor opacity or unwanted texture. Adjustments may include changing squeegee pressure, cleaning the screen, adding more ink or correcting registration. Catching these issues early prevents waste and keeps the batch consistent.

Some jobs can be completed with in-house plastisol screen printing, where the design, screens and printing are handled under one roof. That setup can make it easier to check colour and alignment during the run because decisions stay close to the press. It also means the reader should ask clear questions about artwork requirements, garment choices and proof approval before a job begins.

Layering is another part of the print. When several colours overlap, order matters. The first layer may act as a base for the next one. If a light colour sits over a dark one, it may need enough opacity to stay clean. If two colours touch exactly, registration has to be tight to avoid a thin gap or overlap. Halftones add another level of care because tiny dots can fill in or disappear if the screen or ink settings are wrong.

Curing the ink

After printing, the ink is not finished until it has been cured. Plastisol does not become durable simply because it feels dry to the touch. It needs enough heat for the ink particles to fuse into a solid layer. This is where curing temperature matters. If the ink is undercured, it may crack, wash off or feel tacky. If it is overheated, colours can shift or the garment may be damaged.

A conveyor dryer is commonly used for curing. Garments pass through a heated chamber at a controlled speed. The goal is for the ink layer itself to reach the correct temperature, not just the surface of the fabric. Thick prints, dark garments and heavy fabrics can affect how long that takes. Temperature strips or other checks are often used to confirm the cure rather than relying on guesswork.

Cooling comes next. Once garments leave the heat, the ink firms up as it cools. At this point, the print can be handled, folded and packed. A cured plastisol print should feel flexible and sit smoothly on the fabric. It should not feel sticky, smear under light rubbing or show signs of lifting at the edges.

What this means for the reader

Understanding the process helps when comparing print options or preparing artwork. A simple design with few colours is usually easier to control than a detailed image with many overlapping layers. Large solid areas may need a softer ink feel, while fine text may need a cleaner mesh and sharper stencil. Fabric choice changes the final look, especially when printing on dark or textured garments.

It also helps to know which questions are worth asking before placing an order. Ask how many colours the design needs, whether a proof is available, what garment areas can be printed and how placement is checked. For dark apparel, ask whether an underbase is needed. For a design with small details, ask whether the line weight will hold up at the planned print size.

Production timing is another practical point. Screen setup, exposure, registration, test prints and curing all take time. A repeat job may move faster if artwork and screens are kept ready, while a new design needs more preparation. Rush requests can reduce the time available for careful checks, so it is sensible to plan ahead where possible.

Care instructions matter after the print is finished. Plastisol prints generally last better when garments are washed inside out, using mild settings and avoiding unnecessary high heat. This is not about treating the print gently at all costs. It is about avoiding harsh conditions that stress the ink film or the fabric around it.

One local option is Custom Shirt Printing. For hours, appointment rules, pricing and current printing details, it is worth confirming with whichever business is chosen.

Custom Shirt Printing, 11150 Glenoaks Blvd, Pacoima, CA 91331, USA, phone (323) 406-0702.